

WEATHERMASTER MOUNTING INSTRUCTIONS

A qualified contractor must perform the following ATM mounting instructions:

1. Cut hole in steel wall 21.5 inches high by 17.5 inches wide;
2. Place ATM through the hole in the wall from the front side of the hole so that ATM frame protrudes through the front side of the wall.
3. Looking at the Packing List attach the steel mounting angle labeled "T" to top of the ATM cabinet and also to the front wall with the enclosed hardware or appropriate hardware based on construction of wall;
4. Use leveler to ensure steel ATM cabinet is square;
5. Shim any necessary sides;
6. Attach each of the remaining three mounting angles provided (labeled "L", "R", and "B" to the appropriate sides of the ATM ("L" (left), "R" (right), and "B" (bottom), respectively) and also to the front wall with the provided or appropriate hardware.

NOTE: IN ORDER TO USE THE APPROPRIATE MOUNTING ANGLES, LOOK AT THE PACKING LIST LOCATED INSIDE THE ENVELOPE, OUTSIDE THE BOX.

7. Please note that the dimensions of the ATM frame are 19.5 inches wide by 22.5 inches tall. This is only important so that you leave enough room on each side of the ATM so that the frame does not interfere with any other objects attached to the wall, which the ATM is installed on.

Please contact the Qualtex Corporation service department if you have any questions regarding the ATM installations.

Please note: if the ATM is not "square" in the wall, the rear door may not close properly. Additionally, the slide-out tray may not move in and out of the cabinet smoothly. A leveler must be used on all sides.